



## 20V CORDLESS PRUNING SHEARS

- BODY ONLY

MODEL NO: CP20VPS

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

**IMPORTANT:** PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instructions



Wear eye protection



Wear protective gloves



Keep Dry

### 1. SAFETY

#### 1.1. WORK AREA SAFETY

- ✓ Keep work area clean and well lit. Cluttered or dark areas invite accidents.
- ✗ **DO NOT** operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust. Power tools create sparks which may ignite the dust or fumes.
- ✓ Keep children and bystanders away while operating a power tool. Distractions can cause you to lose control.
- ✓ Avoid body contact with earthed or grounded surfaces, such as pipes, radiators, ranges and refrigerators. There is an increased risk of electric shock if your body is earthed or grounded.
- ✗ **DO NOT** expose power tools to rain or wet conditions. Water entering a power tool will increase the risk of electric shock.

#### 1.2. PERSONAL SAFETY

- ✓ Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication. A moment of inattention while operating power tools may result in serious personal injury.
- ✓ Use personal protective equipment. Always wear eye protection. Protective equipment such as a dust mask, non-skid safety shoes, hard hat or hearing protection used for appropriate conditions will reduce personal injuries.
- ✓ Prevent unintentional starting. Ensure the switch is in the off-position before connecting to power source and/or battery pack, picking up or carrying the tool. Carrying power tools with your finger on the switch or energising power tools that have the switch on invites accidents.
- ✓ Remove any adjusting key or wrench before turning the power tool on. A wrench or a key left attached to a rotating part of the power tool may result in personal injury.
- ✗ **DO NOT** overreach. Keep proper footing and balance at all times. This enables better control of the power tool in unexpected situations.
- ✓ Dress properly. Do not wear loose clothing or jewellery. Keep your hair and clothing away from moving parts. Loose clothes, jewellery or long hair can be caught in moving parts.
- ✗ **DO NOT** let familiarity gained from frequent use of tools allow you to become complacent and ignore tool safety principles. A careless action can cause severe injury within a fraction of a second.
- ✗ **DO NOT** force the power tool. Use the correct power tool for your application. The correct power tool will do the job better and safer at the rate for which it was designed.
- ✗ **DO NOT** use the power tool if the switch does not turn it on and off. Any power tool that cannot be controlled with the switch is dangerous and must be repaired.
- ✓ Remove the battery pack, if detachable, from the power tool before making any adjustments, changing accessories, or storing power tools. Such preventive safety measures reduce the risk of starting the power tool accidentally.
- ✓ Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool. Power tools are dangerous in the hands of untrained users.
- ✓ Maintain power tools and accessories. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use. Many accidents are caused by poorly maintained power tools.
- ✓ Keep cutting tools sharp and clean. Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.
- ✓ Use the power tool, accessories and tool bits etc. in accordance with these instructions, taking into account the working conditions and the work to be performed. Use of the power tool for operations different from those intended could result in a hazardous situation.
- ✓ Keep handles and grasping surfaces dry, clean and free from oil and grease. Slippery handles and grasping surfaces do not allow for safe handling and control of the tool in unexpected situations.
- ✓ Have your power tool serviced by a qualified repair person using only identical replacement parts. This will ensure that the safety of the power tool is maintained.

## 2. INTRODUCTION

Cordless 20V pruning shears - body only. Power assisted pruning shears makes pruning stems and branches quick and easy. Cuts through thin and thicker branches up to 25mm. Brushless motor which gives improved performance and requires less maintenance than the brushed equivalent, making a more efficient, longer lasting tool. Additional safety switch for extra protection. Ergonomic and lightweight in design, this tool makes a great addition to your garden equipment. Requires compatible 20V battery and mains charger, sold separately.

## 3. SPECIFICATION

**Model:** .....CP20VPS  
**Battery** .....20V 2Ah - 6Ah Lithium-ion (not included)  
**Consumable parts** ..... CP20VBP2 - 2Ah Battery,  
.....CP20VBP4 - 4Ah Battery, CP20VBP6 - 6Ah Battery  
**Replacement parts**..... CP20VMC - Mains Charger (not included)  
**Blade Length**.....30mm  
**Running Time:** .....2Ah - 25mins, 4Ah - 45mins, 6Ah - 60 mins  
**Voltage:**..... 20V DC

## 4. FEATURES

1. Lower shear blade
2. Upper shear blade
3. Hex Screw
4. Switch Trigger
5. Blades tightening nut
6. Button of Battery Pack
7. Battery Pack
8. On/Off switch (I/O)



## 5. OPERATION

### 5.1. TURN ON

- 5.1.1. Insert the battery pack.
- 5.1.2. Hold the shears firmly, and slide the I/O switch to the "I" (on) position. The tool makes a single beep to indicate that the I/O switch has been on the "I" (on) position.
- 5.1.3. The shear blades are in locked-mode when the I/O switch is on. To release the lock, depress the switch trigger two times. The upper shear blade opens automatically.
- 5.1.4. To close the shear blade, depress the switch trigger once again.

### 5.2. TURN OFF

- 5.2.1. Depress down and hold on the switch trigger for about three seconds and then the tool makes two ticking sounds.
- 5.2.2. Slide the I/O switch to the "O" (off) position. The tool makes continuous ticking sound to indicate that the I/O switch has been moved to the "O" (off) position.
- 5.2.3. Remove the battery pack.

### 5.3. ACCIDENTAL RE-START PREVENTIVE FUNCTION

- 5.3.1. Even if the battery pack is inserted and switch trigger is pressed when the I/O switch is locked on the "I (ON)" position and the shear blades are on unlocked-mode with the battery removed, the tool does not start to prevent accidental operation. To start the tool, depress the switch trigger two times and then depress the switch trigger once.

### 5.4. AUTO LOCKED-MODE AND SHUT-OFF MODESHIFT

- 5.4.1. For safety reasons, the tool shifts into shut-off mode automatically if the tool is left untouched for approximately 10 minutes: The tool is shift into shut-off mode. Slide the I/O switch to the "O" (off) position once and slide the I/O switch to the "I" (on) position again, then depress the switch trigger two times to release the lock.

### 5.5. PRUNING OPERATION

- 5.5.1. Cut branches one by one. The maximum thickness of branches which can be cut with these shears is about 30mm. Maintain proper footing and balance at all times.

### 5.5.2. AFTER USE

- 5.5.3. Close the shear blades, press the I/O switch to the "O" (off) position, and remove the battery pack. Store the shears in dry, high or locked-up place out of reach of children.

## 6. MAINTAINANCE

### 6.1. REPLACE THE UPPER SHEAR BLADE

- 6.1.1. Insert the battery pack. Remove the blade cover.
- 6.1.2. Switch on the tool, and pull the switch trigger to open the upper shearblade fully.
- 6.1.3. With the upper shear blade open, switch off the tool and remove the battery pack.
- 6.1.4. Remove the hex screw (fig.1.1) near the shear blades with the hex wrench by turning it anticlockwise. Remove the blades tightening nut (fig.1.2) near the shear blades with a suitable wrench or alike by turning it anticlockwise and take out the washer (fig.1.3).
- 6.1.5. Remove two bolts (fig.2.1) near the shear blades with a hexwrench by turning anticlockwise. Remove the head cover (fig.2.2) by separating the tongue on the head cover from the groove of the housing. Take out the upper shear blade assembly.
- 6.1.6. Remove the circlip on the link arm (fig.3.1) with circlip pliers and replace the upper shear blade (fig.3.2) with a new one.
- 6.1.7. To install the upper shear blade, perform the removal steps in reverse. When installing the shear blades, pay attention to the following points:
  - 6.1.8.1. Apply machine lubricating oil (not included, please see [www.sealey.co.uk](http://www.sealey.co.uk) for more information) on to the shear blade.
  - 6.1.9. When installing the head cover, align the tongue of the head cover with the groove of the housing.
  - 6.1.10. Make sure all the bolts are securely tightened. After installing the blade, always adjust blade clearance. (Refer to section 7.2)




fig.1




fig.2




fig.3

### 6.2. LUBRICATING THE SHEAR BLADE

- 6.2.1. The shear blades require lubricating every time before using. To apply machine oil (not included, please see [www.sealey.co.uk](http://www.sealey.co.uk) for more information) on to the shear blades, perform the following steps:
  - 6.2.2. Insert the battery pack. Remove the blade cover.
  - 6.2.3. Switch on the tool, and pull the switch trigger to open the upper shearblade fully.
  - 6.2.4. With the upper shear blade open, switch off the tool and remove the battery pack.
  - 6.2.5. Remove the hex screw (fig.4.1) near the shear blades with the hex wrench by turning it anticlockwise. Squeeze the oil from the machine oil bottle into the threaded hole (fig.4.2).
  - 6.2.6. Reinstall the hex bolt by turning it clockwise.
  - 6.2.7. Turn on the tool and operate several times to distribute the lubricant evenly.

### 6.3. ADJUSTMENT FOR BLADE CLEARANCE

- 6.3.1. From time to time, adjust the clearance of the shear blades as follows:
  - 6.3.2. Insert the battery pack. Remove the blade cover.
  - 6.3.3. Switch on the tool, and pull the switch trigger to open the upper shearblade fully.
  - 6.3.4. With the upper shear blade open, switch off the tool and remove the battery pack.
  - 6.3.5. Loosen the hex screw (fig.5.1) near the shear blades with the hex wrench by turning it anticlockwise (fig.5).
  - 6.3.6. Adjust the tightness of the blades tightening nut (fig.5.2) with a suitable wrench by turning it clockwise or anticlockwise (fastening torque for the blade tightening nut: approximately 0.5 Nm).
  - 6.3.7. Tighten the hex bolt again.
  - 6.3.8. Check the tightness of the blades whether the blades never rattle or swing sideways. If the blades are too tight or loose, adjust the clearance again.




fig.4




fig.5

#### 6.4. BLADE MAINTENANCE

- ❑ **WARNING!** Failure to perform blade maintenance may cause excessive blade friction and shorten the operating time per battery charge.

- 6.4.1. Before and after operation, check the shear blades carefully. After operation, clean off the blades with a stiff brush.
- 6.4.2. Then wipe the blades with a cloth. And apply machine oil onto the blade edge and movable part.





#### 6.5. SHARPENING BLADES

##### Upper shearblade

- 6.5.1. Apply the flat surface of the diamond file (not included, please see [www.sealey.co.uk](http://www.sealey.co.uk) for more information) to the blade edge. Push the diamond file towards the tip of the blade to sharpen along the entire blade edge. Maintain the same flat contact with the file consistently along the entire blade edge (fig.6).
- 6.5.2. Apply the flat surface of the diamond file lightly to the opposite side of the blade. Move the diamond file towards the tip of the blade lightly to remove burrs (fig.7).

##### Lower shearblade

- 6.5.3. Apply the round surface of the diamond file to the blade edge. Push the diamond file towards the tip of the blade to sharpen along the entire blade edge (fig.8).
  - 6.5.4. Apply the flat surface of the diamond file lightly to the opposite side of the blade. Move the diamond file towards the tip of the blade lightly to remove burrs (fig.9).
- \* **DO NOT** sharpen this side too much. File lightly only for removing burrs. Otherwise the blade clearance may become too much or the blade life may be shortened.



## 7. TROUBLESHOOTING

- ❑ **Warning!** Remove battery before carrying out any maintenance.

PROBLEMS	POSSIBLE CAUSE	SOLUTION
The shear blade does not move even after pulling the switch trigger.	The battery is low.	Charge the battery.
	I/O switch is "Off" position.	Press the I/O switch to "I" position.
	The shears are locked.	Unlock the shears by performing the steps in "Switch action".
	I/O switch is "on" position when inserting the battery pack.	Press the I/O switch to the "O" (off) position Once, and press the I/O switch to the "I" (on) position again.
The shear blades are stuck on the branch.	Switch trigger defect.	Stop using the tool immediately, and ask your local authorized service centre for repair.
	The branch is too thick.	Release the switch trigger. Press the I/O switch to "O" position. Then pull the blades straight out slowly from the branch.
The cut is not smooth.	The shear blades are dull.	Sharpen the shear blades, or adjust blade clearance.
	The shear blades are worn out.	Replace the shear blades.



#### WEEE REGULATIONS

Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste authority for recycling information.



#### ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.

**Note:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

**Important:** No Liability is accepted for incorrect use of this product.

**Warranty:** Guarantee is 12 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk



www.sealey.co.uk