


PARTS LIST FOR SUPERMIG TORCH Models 185.V2, 195, 220.V5, 235.V4




ltem	Part No	Description	ltem	Part No	Description
1	120/722007	Ring nut	10	168.200105	Nozzle, Cylinder TR - 15
2	120/722013	Nut, Liner retainer	10	120/722423	Nozzle, Conical TR - 15
3	120/722305	Lance and Diffuser TB15	11	168.301535	Liner,T, 0.6 - 0.8mm 3mt Steel
5	120/722319	Spring for nozzle	11	120/722689	Liner,T, 1.0 - 1.2mm 3mt Steel
6	120/722326	Insulation, diffuser	13	120/722441	Termination connector
7	120/742172	Torch holder	14	120/742175	Gun plug housing
8	120/722415	Contact tip 0.6mm (AF1)	15	120/722171	Ring nut
8	120/722416	Contact tip 0.8mm(AF1)	16	120/722325	Front torch part
8	120/722552	Contact tip 1.0mm ALLY (AF1)	17	120/722693	Insulation Block, Torch part
8	120/722553	Contact tip 1.2mm ALLY (AF1)			
8	120/722556	Contact tip 0.8mm ALLY			

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. **IMPORTANT:** No liability is accepted for incorrect use of product. **WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim. **INFORMATION:** For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address including your postcode.

CHARLES POWER Sole UK Distributor	O1284 757500 O1284 757500 O	www.sealey.co.uk
DOWER Sole UK Distributor Scaley Group, Bury St. Edmunds, Suffolk.	📇 01284 703534	sales@sealey.co.uk

PARTS LIST FOR Model: SUPERMIG 195






nPart NoDescription120.113858Potentiometer120/112125Knob,Potentiometer120/112183Protection,rectifier120/112227Rectifier120.114306Wire feed PCB120.113533Potentiometer120.322901Knob for switch120/122329Thermostat120.121510Switch120/122305Electro-valve120/122707Light120/1220302Cable	
120/112125Knob,Potentiometer120/112183Protection,rectifier120/112227Rectifier120.114306Wire feed PCB120.113533Potentiometer120.322901Knob for switch120/122329Thermostat120/12235Electro-valve120/122075Light	
120/112183 Protection, rectifier 120/112227 Rectifier 120.114306 Wire feed PCB 120.113533 Potentiometer 120.322901 Knob for switch 120/122329 Thermostat 120/122035 Electro-valve 120/122077 Light	
120/112227 Rectifier 120.114306 Wire feed PCB 120.113533 Potentiometer 120.322901 Knob for switch 120/122329 Thermostat 120/12510 Switch 120/122035 Electro-valve 120/12277 Light	
120.114306 Wire feed PCB 120.113533 Potentiometer 120.322901 Knob for switch 120/122329 Thermostat 120.121510 Switch 120/122035 Electro-valve 120/122707 Light	
120.113533 Potentiometer 120.322901 Knob for switch 120/122329 Thermostat 120.121510 Switch 120/122035 Electro-valve 120/122707 Light	
120.322901 Knob for switch 120/122329 Thermostat 120.121510 Switch 120/122035 Electro-valve 120/122707 Light	
120/122329 Thermostat 120.121510 Switch 120/122035 Electro-valve 120/122707 Light	
120.121510 Switch 120/122035 Electro-valve 120/122707 Light	
120/122035 Electro-valve 120/122707 Light	
120/122707 Light	
5	
120/120302 Cable	
MC3CX2.5 Mains cable	
120/152054 Blade,fan	
120/152110 Motor,fan	
120/153007 Wire feed motor	
120/169371 Reactance	
120.169296 Transformer	
B/609Z Counter roller (bearing)	
120/312137 Knob	
120/322081 Spindle, sleeve/spacer type	
120/322112 Bushing, cable	
120/322126 Casing, feeder roller shaft	
120/322127 Casing, torch fixing	
120/322128 Bracket, counter roller	
120/723051 Connection, torch	
120/322180 Spacer collar	
120/322200 Wheel (fixed)	
120/322246 Wheel	
120.322641 Plastic frame	
120/422257 Knob, counter roller tension	
120/422817 Bracket, axle	
120/422969 Bracket, castor	
120/432102 Bull nosed adaptor (not show	n)
120/452022 Spring, counter roller tension	
120/452057 Spring	
120/312328 Handle	
120/644757 Back panel	
120/644078 Diaphragm 120/644606 Bracket (bottle)	
(,	
•	
120.644961 Bottom (black) 120.655320 Cover	
120.655319 Door	
120/681092 Axle, wheel	
120/712030 Clamp, earth	
120/722019 Feed roller 0.6 - 0.8	
120/742180 TORCH	
REG/MT Regulator (2 gauges) not sho	wn
120/990097 Guide hose	WIII
120/990257 Gear set	
120/990264 Spindle Kit	

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. **IMPORTANT:** No liability is accepted for incorrect use of product. **WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim. **INFORMATION:** For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address including your postcode.

SCALL POWER WELDERS	Sole UK Distributor	O1284 757500 O1284 757500 O	www.sealey.co.uk
COLCULLE U WELDERS	Bury St. Edmunds, Suffolk.	📇 01284 703534	email sales@sealey.co.uk



NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. **IMPORTANT:** No liability is accepted for incorrect use of product. **WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim. **INFORMATION:** For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address including your postcode.

