



ITEM	PART NO	DESCRIPTION	ITEM	PART NO	DESCRIPTION
1	CP1201.01	CHUCK SCREW (L.H)	11	CP1201.11	FORWARD/REVERSE ROD
2	CP1201.02	KEYLESS CHUCK 1/2"	12	CP1201.12	SWITCH ASSEMBLY
3	CP1201.03	GEAR CASE	13	CP1201.13	BATTERY CONNECTOR ASS'Y
4	CP1201.04	MOTOR GEAR	14	CP1201.14	SPRING PLATE
5	CP1201.05	MOTOR	15	CP1201.15	CASING SCREW
6	CP1201.06	SPEED SELECTOR SLIDE BUTTON	16	CP1201.16	HOUSING CONNECTION CLIP
7	CP1201.07	SPEED SELECTOR SPRING	17	CP1200BP	C/LESS POWER TOOL BATTERY 12V LI-ION
8	CP1201.08	CASING ASS'Y	18	CP1200MC	LI-ION BATTERY CHARGER 12V 1 HOUR (NOT SHOWN)
9	CP1201.09	LED COVER	19	CP1200CB	CANVAS BAG FOR CP1200 SERIES(NOT SHOWN)
10	CP1201.10	BELT CLIP			