



Issue Date: 16/02/01
 Version No: 1
 Date Modified: N/A

Item	Part No.	Description	Item	Part No.	Description	Item	Part No.	Description
1	3001LE/1-1	Front wheel shaft.	31	3001LE/13-1	Frame	59	3001LE/5-0	Power unit assembly
2	3001LE/1-3	Front wheel.	32	3001LE/13-3	Spring	60	3001LE/5-1	Tank nut
3	3001LE/1-4	Snap ring.	33	3001LE/13-5	Stopper	61	3001LE/5-11	Washer
4	3001LE/10-0	Release valve assembly.	34	3001LE/2-1	Saddle	62	3001LE/5-13	O - ring
5	3001LE/10-1	Release valve.	35	3001LE/2-10	Cotter pin	63	3001LE/5-14	Piston packing retainer
6	3001LE/10-2	O - ring.	36	3001LE/2-11	Spring washer	65	3001LE/5-4	Cylinder
7	3001LE/10-3	Release valve gear.	37	3001LE/2-12	Nut	66	3001LE/5-5	Piston rod
8	3001LE/10-4	Collar.	38	3001LE/2-2	Saddle base	67	3001LE/5-7	Back up ring
9	3001LE/10-5	Release valve lock nut.	39	3001LE/2-3	Link rod pin (A)	69	3001LE/5-9	O - ring
10	3001LE/10-6	Release valve connecting rod	40	3001LE/2-4	Arm pin (A)	70	3001LE/6-1	Oil box
11	3001LE/10-7	Steel ball.	41	3001LE/2-5	Link rod	71	3001LE/6-11	Back up ring
12	3001LE/10-8	Copper washer.	42	3001LE/2-6	Link pin (B)	72	3001LE/6-2	Bolt
13	3001LE/11-0	Handle fork assembly.	43	3001LE/2-7	Nut	73	3001LE/6-3	Oil filter
14	3001LE/11-1	Plunger connecting pin	44	3001LE/2-8	Spring washer	74	3001LE/6-4A	Steel ball 9mm
15	3001LE/11-2	Rivet	45	3001LE/2-9	Washer	75	3001LE/6-4B	Steel ball 6mm
16	3001LE/11-3	Handle fork.	46	3001LE/3-0	Lift arm assembly	76	3001LE/6-6	Washer
17	3001LE/11-4	Handle shaft (A)	47	3001LE/3-10	Pin	77	3001LE/6-7	Bolt
18	3001LE/11-5	Handle shaft (B)	48	3001LE/3-11	Snap ring	78	3001LE/7-1	Oil tank
19	3001LE/11-6	Spring washer	49	3001LE/3-12	Arm pin	79	3001LE/7-3	Oil fill plug
20	3001LE/11-7	Spring	50	3001LE/3-3	Lift arm	80	3001LE/7-4	O - ring
21	3001LE/12-0	Handle assembly	51	3001LE/3-5	Piston connecting joint	81	3001LE/8-1	Pump plunger
22	3001LE/12-2	Handle set screw	52	3001LE/3-7	Cotter pin	82	3001LE/8-2	Back up ring
23	3001LE/12-21	Lower handle	53	3001LE/3-9	Link rod	83	3001LE/8-3	O - ring
24	3001LE/12-22	Upper handle	54	3001LE/4-0	Castor assembly	84	3001LE/8-4	Oil seal
25	3001LE/12-23	Spring pin	55	3001LE/4-10	Bolt	85	3001LE/9-1	Safety valve plug cap
26	3001LE/12-24	Handle connecting bolt	56	3001LE/4-7	Nut	86	3001LE/9-2	Rubber packing
27	3001LE/12-3	Release valve gear (small)	57	3001LE/4-8	Spring washer	87	3001LE/9-3	Retainer
28	3001LE/12-4	Release valve connecting bar	58	3001LE/4-9	Spring washer	88	3001LE/9-4	Spring retainer
29	3001LE/12-5	Cotter pin				89	3001LE/9-5	Spring
30	3001LE/12-7	Nut				90	3001LE/RK	Repair kit

IMPORTANT: NO RESPONSIBILITY IS ACCEPTED FOR INCORRECT USE OF THE MACHINE.

Hydraulic products are only repaired by local service agents. We have service/repair agents in all parts of the UK. **DO NOT RETURN JACKS TO US.** Please telephone us on 01284 757500 to obtain the address and phone number of your local agent. If Jack is under guarantee please contact your dealer.

WARRANTY: GUARANTEE IS 12 MONTHS FROM PURCHASE DATE. PROOF OF PURCHASE WILL BE REQUIRED FOR ANY CLAIM.