



Issue: 1
 Issue Date: 120315

ITEM	PART NO	DESCRIPTION	ITEM	PART NO	DESCRIPTION
1	3290CX.01	LIFT ARM ASSEMBLY	17	3290CX.17	ARM SHAFT
2	3290CX.02	HANDLE	18	3290CX.18	BOLT LINK
3	3290CX.03	HANDLE SOCKET	19	3290CX.19	LOCK WASHER
4	3290CX.04	HANDLE BOLT	20	3290CX.20	LOCK WASHER
5	3290CX.05	PLUNGER PIN	21	3290CX.21	LOCK NUT
6	3290CX.06	SIDE FRAME	22	3290CX.22	SADDLE SHAFT
7	3290CX.07	LOCK WASHER	23	3290CX.23	SADDLE
8	3290CX.08	LOCK NUT	24	3290CX.24	POWER UNIT ASSEMBLY
9	3290CX.09	SOCKET HEAD CAP SCREW	25	3290CX.25	COTTER PIN
10	3290CX.10	CASTOR ASSEMBLY	26	3290CX.26	RETAINING RING
11	3290CX.11	STUD	27	3290CX.27	FRONT WHEEL
12	3290CX.12	BOLT, LEFT	28	3290CX.28	RETAINING RING
13	3290CX.13	LOCK WASHER	29	3290CX.29	RETURN SPRING
14	3290CX.14	SPLIT LOCK WASHER	30	3290CX.30	BLOCK
15	3290CX.15	RETURN SPRING	31	3290CX.31	BOLT
16	3290CX.16	RETAINING RING			

PUMP BREAKDOWN

ITEM	PART NO	DESCRIPTION
1	3290CX.P01	BASE PLATE
2	3290CX.P02	STEEL BALL
3	3290CX.P03	RECTANGLE RING
4	3290CX.P04	WASHER
5	3290CX.P05	ALUMINIUM WASHER
6	3290CX.P06	GEAR
7	3290CX.P07	LOCK NUT
8	3290CX.P08	VALVE CONNECT
9	3290CX.P09	WASHER
10	3290CX.P10	VALVE NUT
11	3290CX.P11	O-RING
12	3290CX.P12	RELEASE CORE
13	3290CX.P13	SEAL RING
14	3290CX.P14	O-RING
15	3290CX.P15	BOWL WASHER
16	3290CX.P16	PISTON
17	3290CX.P17	OIL FILLER PLUG
18	3290CX.P18	RESERVOIR
19	3290CX.P19	CYLINDER
20	3290CX.P20	TOP CAP
21	3290CX.P21	O-RING
22	3290CX.P22	PISTON ROD
23	3290CX.P23	O-RING
24	3290CX.P24	RETAINING RING
25	3290CX.P25	PLUNGER
26	3290CX.P26	RETURNING RING
27	3290CX.P27	OIL FILLER PLUG
28	3290CX.P28	STEEL BALL
29	3290CX.P29	RELEASE VALVE NUT
30	3290CX.P30	SAFETY VALVE SPRING
31	3290CX.P31	O-RING
32	3290CX.P32	SPRING BASE
33	3290CX.P33	STEEL BALL
34	3290CX.P34	RECTANGLE RING
35	3290CX.P35	NUT
36	3290CX.P36	O-RING
37	3290CX.P37	TAPER SPRING
38	3290CX.P38	STEEL WASHER
39	3290CX.P39	SAFETY VALVE COVER
40	3290CX.P40	OIL FILTER SCREEN
41	3290CX.P41	O-RING

Issue: 1
 Issue Date: 120315

