



Issue: 2
 Issue Date: . . . 020305

No.	Stock Code	Description
1	SM100/001	Hex Bolt
2	SM100/002	Screw
3	SM100/003	Spring washer
4	SM100/004	Dust Proof Cover
5	SM100/005	Base
6	SM100/006	Hex. Bolt
7	SM100/007	Bush
8	SM100/008	Dust Proof Plate
9	SM100/009	Belt Support
10	SM100/010	Arrow Mark
11	SM100/011	Cam
12	SM100/012	Hex Nut- Looseproof
13	SM100/013	Press Block
14	SM100/014	Adjusting Rod
15	SM100/015	Hex. Nut
16	SM100/016	Sliding Block
17	SM100/017	Pin
18	SM100/018	Adjusting Block
19	SM100/019	Spring
20	SM100/020	Spring Stop Plate
21	SM100/021	Upper Support
22	SM100/021	Cap Screw
23	SM100/023	Block Stop Plate
24	SM100/024	Lower Support
25	SM100/025	Movable Cover
26	SM100/026	Aluminium Roller
27	SM100/027	Hex. Nut
28	SM100/027	Rubber Roller
29	SM100/029	Snap Ring
30	SM100/030	Ball Bearing
31	SM100/031	Bush
32	SM100/032	Shaft
33	SM100/033	Snap Ring
34	SM100/034	Sanding Belt
35	SM100/035	Washer
36	SM100/036	Hex. Shaft
37	SM100/037	Protection Cover
38	SM100/038	Hex. Bolt
39	SM100/039	Ball Knob
40	SM100/040	Screw Shaft
41	SM100/041	Cam Shaft
42	SM100/042	Loosen-Tighten Plate
43	SM100/043	Adjusting Plate
44	SM100/044	Cover Screw
45	SM100/045	Wave Washer
46	SM100/046	Cover Plate
47	SM100/047	Cover
48	SM100/048	Tracking Knob
49	SM100/049	Spring
50	SM100/050	Washer

No.	Stock Code	Description
51	SM100/051	Cap Screw
52	SM100/052	Washer
53	SM100/053	Working Table
54	SM100/054	Sanding Stop Plate
55	SM100/055	Wing Nut
56	SM100/056	Support Plate
57	SM100/057	Screw
58	SM100/058	Washer
59	SM100/059	Hex. Bolt
60	SM100/060	Dust Collector
61	SM100/061	Eye Shield
62	SM100/062	Washer
63	SM100/063	Hex. Nut
64	SM100/064	Screw
65	SM100/065	Rear Protector
66	SM100/066	Fan
67	SM100/067	Rear Support
68	SM100/068	Ball Bearing
69	SM100/069	Rotor
70	SM100/070	Stator Housing
71	SM100/071	Ball Bearing
72	SM100/072	Front Support
73	SM100/073	Screw
74	SM100/074	Screw
75	SM100/075	Switch Box Cover
76	SM100/076	Switch Box
77	SM100/077	Screw
78	SM100/078	Supporting Plate
79	SM100/079	Screw
80	SM100/080	Strain Relief
81	SM100/081	Power Cord
82	SM100/082	Wiring Box Cover
83	SM100/083	Packing
84	SM100/084	Screw
85	SM100/085	Capacitor Sleeve
86	SM100/086	Running Capacitor
87	SM100/087	Capacitor Cover
88	SM100/088	Plug
89	SM100/089	Plug Socket
90	SM100/090	Packing
91	SM100/091	Wire Connector
92	SM100/092	Wiring Box
93	SM100/093	Screw
94	SM100/094	Int. Washer
95	SM100/095	Packing
96	SM100/096	Screw
97	SM100/097	Copper Set
98	SM100/098	Ext. Washer
99	SM100/099	Strain Relief
100	SM100/100	Screw

SM100 Wiring diagram

